

MOBY

cm 80x44x182 h

ondis24®

Gardening Storage Toys and more

IT - Istruzioni per il montaggio

GB - Assembly instruction

DE - Montageanleitungen

FR - Instructions pour le montage

ES - Instrucción para el montaje

NL - Instructies voor de montage

TR - Montaj talimatları


GR - Οδηγίες συναρμολόγησης





RU - Инструкции за монтаж










RO - Instrucțiuni de montaj




CZ - Návod na montáž

PL - Instrukcja montażu




A**1x A1****2x A2****2x A3****1x A4****1x A5****2x****1x A6****1x A7****B****4x B1****2x****2x B2****2x B4****1x B3****1x****6x [4,5X25]****C****1x C1****1x C2****1x C3****1x C4****1x C5****2x C7****2x C8****1xC10****1xC11**


D**2x D1****2x D2****1x D3****1x D4****1x D5****1x D6****1x D7****1x D8****D20****2x D21****D22****2x D23****4x****6x****10x [4,5X25]****1x****E****4x E1****4x****2x****2x****E2****E3**

A**01****02****03**


04



05




06




B


07




08




09









10




11







18




19




20




21









22







23





4,5X25 x 6








4,2X22 x 4



31



32

